



祥昊科技有限公司

SHOCKINDICATOR ENTERPRISE CO.,LTD

TILTINDICATOR PLUS



SPECIFICATION

Product name	Tiltindicator Plus
Dimension	120 x 120 x 7.7 mm
Operating temperature	-40°C ~ +60°C (-40°F ~ 140°F)
Activation angle	Activation angle : Tilt to Left 30°, 40°, 50°, 60°, 70°, 80° Tilt to Right 30°, 40°, 50°, 60°, 70°, 80° Overturn 180°
Components :	Brass beads, ABS, Polycarbonate, Semigloss Gloss Paper
Shelf life	2 years
Packing	50pcs/box

DESCRIPTION

Tiltindicator Plus is applied to the packaging and provides evidence of mishandling if the shipment is tilted. Providing 360° monitoring of goods that must keep upright. When the parcel has tilted, the brass balls move to the corresponding tilt angle, providing disputable evidence of mishandling. As a visual reminder to handle with care as carriers know the package is being monitored.

FEATURES

- △ Independent Barcode & Tamper-proof
- △ Protect fragile, sensitive or calibrated goods while in-transit.
- △ Alert carriers that careful handling is mandatory – visual deterrent.
- △ Provide evidence that mishandling occurred.
- △ Enhance image with customer, restores faith in your ability to delivery product safely.

ACCESSORY



1. HOLD TILTWATCH PLUS IN UPRIGHT POSITION
2. PULL TAB STRAIGHT DOWN TO ARM
3. AFFIX TO CARTON IMMEDIATELY IN UPRIGHT POSITION
4. DO NOT TILT LEFT OR RIGHT

Warning label

Length x Width: 120 x 120 mm

1. Drawing the Attention of a delivery man.
2. Clearly indicate the Processing Steps for activated the label (brass balls move to indicate tilt angle)

Small sticker

Length x Width: 16 x 120 mm


Instructions for installing the indicator.


INSTRUCTIONS


1. Rip off the safety seal of the Tiltindicator Plus in the correct position.
2. Write the degree of unacceptable tilt on the Companion Label and apply it next to the indicator.
3. Place the Alert Sticker on bill of lading.



CONTACT US

 +886-2-26983553

 +886-2-26932936

 admin_147030

 admin@shock-indicator.com

 xiang-hao.com.tw/en/

